


Part #	(A)	(B)	(C)	(D)	(E)	(F)	(G)	(H)	(I)	(J)	(K)
Sketch											
Description	Glides	Casters	Base	Column	Column Cover	Footring+height adjusting knob	Seat & Backrest Bolts	Seat mounting plate with backrest arm	Seat	Backrest	Backrest bracket
Quantity	5	5	1	1	1	1	6	1	1	1	1

Seat assembly

Base/Column assembly

1. Insert Glides (A) or Casters (B) into each of the five legs of base (C).
2. Insert column (D) firmly into center of base.
3. Slide footring (F) onto column with ring facing upwards and place at desired location.
4. Slide column cover (E) over column.
5. Tighten footring knob well to assure that it stays in place. **Note:** There is a rubber sleeve in the center of footring. To prevent scratching of column when tightening knob, be sure that the sleeve is in place and when tightening be careful to tighten over the rubber sleeve.


1. Align seat mounting plate/backrest arm(H) with screw holes in underside of seat (I).
Loosely insert all four seat bolts (G) through holes on seat mounting plate/backrest arm(H) into screw holes on underside of seat (I) and tighten only slightly, using the provided Allen key.
After all four seat bolts (G) are properly inserted, tightly secure them in a crossed fashion.
2. Once seat mounting plate has been attached to seat, place seat over upper portion of column and push down firmly.

Backrest assembly


1. Place backrest bracket (K) onto top of plate.
2. Hold backrest (J) over bracket and align holes on bracket to holes on backrest.
3. Using the provided Allen key, tightly secure the two backrest bolts (G) to backrest.



Bottom portion assembly



Seat assembly



Step 1.

Backrest assembly

