




Care & Maintenance Instructions

Robo Portable Room Dividers

National Public Seating is committed to providing high quality furniture that will last for years.

With proper care and maintenance, your furniture will look its best for many years to come.



Robo Dividers – General Care & Maintenance Instructions

NPS Robo Dividers are built to last, and with a little help from you, will stay strong and clean for years to come. Here are some tips:

- Preserve your divider's condition by keeping the relative humidity level in the environment between 30% and 40%.
- Place your dividers away from heat sources such as radiators, heating vents, and wood-burning stoves.
- Shield your furniture from extensive periods of direct sunlight exposure and extreme temperatures to keep the finish pristine.
- Use the Robo Divider on a stable, level surface. Ensure the operating environment is free of obstructions that could impede its movement.
- Maintaining your divider is as simple as having a soft dry cloth to regularly clean it!
- Periodically inspect the mechanical parts for wear and tear. Look for loose screws, bolts, or any signs of damage.
- Apply a small amount of lubricant to moving parts every six months to ensure smooth operation.
- Store the Robo Divider in a cool, dry place when not in use. Also, handle it with care. Avoid dropping or subjecting it to rough use, as this can damage internal components.



Powdercoated Steel & Aluminium

*Always test a new cleaning product
in an inconspicuous area to ensure it is safe to use*

KEEP IT SIMPLE

- Regularly clean the frame system with a gentle cleaning solution to prevent the buildup of dirt and grime. Promptly clean up any spills to prevent staining.

KEY CLEANING SOLUTIONS

- Create a solution using a mild dish soap and warm water, and with a damp cloth, wipe off any marks.

DRYING IMPORTANCE

- After cleaning, use a dry, clean cloth to wipe the frame dry thoroughly. Ensure that no water is left on the surface to prevent damage.

WHAT TO AVOID

- Avoid using harsh cleaners or abrasives on the powder-coated parts. These can damage the finish and cause it to fade or chip. Also, extreme temperatures can damage the finish and make it more susceptible to chipping and cracking.



Plastic

*Always test a new cleaning product
in an inconspicuous area to ensure it is safe to use.*

KEEP IT SIMPLE

- Regularly clean the parts with a gentle cleaning solution to prevent the buildup of dirt and grime. Promptly clean up any spills to prevent staining.

KEY CLEANING SOLUTIONS

- Create a solution using a mild dish soap and warm water. With a sponge, wipe thoroughly.

DRYING IMPORTANCE

- Dry the parts completely with a dry cloth or paper towels to prevent water spots and streaks.

STAIN REMOVAL

- For stubborn stains, sprinkle baking soda directly on the stain and scrub gently with a damp soft-bristled brush or sponge.

WHAT TO AVOID

- Avoid using abrasive cleaners or scrubbers, as they can scratch the plastic surface.



Whiteboard

Always test a new cleaning product in an inconspicuous area to ensure it is safe to use.

KEEP IT SIMPLE

- To prevent heavy staining, regularly clean the whiteboard panels with a dry cloth or eraser after each use. This helps to remove fresh marker ink and keep the surface in good condition.

KEY CLEANING SOLUTIONS

- Isopropyl alcohol and hydrogen peroxide are very effective ways to clean whiteboards and get rid of ghosting caused by chemical build up residue from whiteboard markers.

DRYING IMPORTANCE

- Ensure the whiteboard panels are completely dry before using it again. Use a dry, clean cloth to wipe away any remaining moisture.

STAIN REMOVAL

- If there are stubborn stains or the board needs a deeper clean, mix a solution of equal parts water and isopropyl alcohol. You can also use a commercial whiteboard cleaner.

MASTERING RESIDUAL REMOVAL

- Use a soft, dry cloth or whiteboard eraser to remove a dry residue, such as leftover marker ink or dust. Gently wipe the surface in a circular motion.

WHAT TO AVOID

- Avoid using abrasive cleaners or harsh chemicals, as they can damage the whiteboard surface. Stick to mild solutions like water and isopropyl alcohol.



Acrylic

Always test a new cleaning product in an inconspicuous area to ensure it is safe to use.

KEEP IT SIMPLE

- Use a soft, microfiber cloth to gently dust the acrylic panels. Avoid using abrasive cloths or paper towels that can scratch the acrylic.

KEY CLEANING SOLUTIONS

- Clean the acrylic with a solution of mild soap and water. Dampen a soft cloth with the solution and gently wipe the surface. Rinse with a clean, damp cloth and dry with a soft, lint-free cloth.

DRYING IMPORTANCE

- Proper drying ensures that the acrylic remains clear and transparent, which is essential for its intended function and aesthetic appeal.

RESTORATION

- If the acrylic becomes dull or lightly scratched, use a specialized acrylic polish and a clean, soft cloth. For deeper scratches, consider using a plastic polishing kit designed for acrylic. Follow the manufacturer's instructions carefully to avoid further damage.

SAFETY PRECAUTIONS

- When cleaning or maintaining the acrylic, use tools and materials specifically designed for acrylic care to avoid damage.

WHAT TO AVOID

- Do not use ammonia-based cleaners, alcohol, or other harsh chemicals on acrylic as they can cause damage and clouding. Also, avoid using any cleaning tools or materials that can scratch the acrylic surface.



Fabric Upholstered PET

*Always test a new cleaning product
in an inconspicuous area to ensure it is safe to use.*

KEEP IT SIMPLE

- Begin by vacuuming the PET upholstered panels to remove loose dirt, dust, and debris. Use a soft brush attachment or a handheld vacuum with a brush nozzle to gently lift dirt from the surface.

STAIN REMOVAL

- To clean thoroughly, dampen a sponge or microfiber cloth with a cleaning solution, ensuring it's not dripping wet, rather just damp. Wipe down each surface in small sections, avoiding metal components like buttons and frame legs to prevent rust stains.

DRYING IMPORTANCE

- Use a towel or dry cloth to thoroughly dry the PET panels to prevent water spots and fabric loosening. Allow the room divider to air dry completely in a well-ventilated area before storing or using it.

WHAT TO AVOID

- Do not use abrasive cleaners or steel wool, as these can damage the upholstered panels.